

IRIS BY STARCK® INSTALLATION.

1




Plug the computer
into a power outlet.

2




Turn on the computer and **press the "DEL" key several times** to enter the BIOS.

3



Go to the "SECURITY" tab and select "SECURE BOOT".

4



If the **"SECURE BOOT SUPPORT"** option is "ENABLED", set it to **"DISABLED"**.

5



Select the "SAVE & EXIT" tab, then **"SAVE CHANGES AND RESET"** to restart.

6



After the system restarts, **shut down the computer.**

7



Insert ONLY the IRIS BY STARCK®
USB drive.

8



Connect the computer to the internet using an RJ45 cable (not included).

9



Turn on the computer and **press F11 several times** until the boot menu appears.

10



In the boot menu :
select the line that begins with "UEFI".

11



The installation will begin, please wait until the computer restarts.
The computer's **default password** is on your SECURE.ID card.

12



Click the "IRIS Hardware test" icon and run the test. Once it's successful, a new icon will appear.

13



Click on the "IRIS Installer" icon and enter your installation code shown on your SECURE.ID card.

14



The installation of IRIS BY STARCK® is starting.
The time it takes depends on your internet speed, **please wait.**

15



The computer is restarting.
The computer's default password is on your SECURE.ID card.

16



Installation is complete.
Launch IRIS BY STARCK® and sign up.

17



When you register, enter your license number shown on your SECURE.ID card.

**Your USB drive :
a reusable tool.**

Once your computer is set up, you're free to use your USB drive as it suits you best.